


schönbuch.




AKIRA


Montageanleitung
Assembly instructions

AKIRA

Feste Ablagefläche
mit 2 Steckdosen.
*Fixed shelf conceals two
electrical sockets.*




*Schiebedeckel
Sliding lid*




Das Klappenfach lässt
sich durch seitliche
Griffmulden öffnen.
*The front flap can be
opened via the grip
recesses on the sides.*

AKIRA



Die Schreibfläche enthält einen
Push-to-open Mechanismus
und wird im geöffneten Zustand
über eine magnetische Arretierung
fixiert.

*The desktop contains a
push-to-open mechanism and
is fixed in place by a magnetic
catch when open.*




Ausbau der Steckdose:

1. Abdeckung der Steckdose entfernen
2. Schrauben Lösen

Removing the socket:

1. remove the cover of the socket
2. loosen screws



Demontage und Entsorgung

Werfen Sie das Produkt nicht in den Hausmüll.
Trennen Sie bitte vor der Entsorgung die Elektrobauteile von dem Möbel und führen Sie diese einer geordneten Entsorgung, z. B. bei einer Sammelstelle für Elektroaltgeräte zu. Bitte beachten Sie hierzu die Anleitung zur Demontage.



Disassembly and disposal

Do not dispose the product in the domestic waste. Before disposing the product, please separate the electrical components from the furniture and dispose them in an orderly manner, e.g. at a collection point for used electrical appliances. Please follow the instructions for disassembly.

Technische Änderungen
im Sinne von Verbesserungen vorbehalten.
*The right to introduce
technical improvements is reserved.*