


INSTRUCTIONS /
BRUGSVEJLEDNING
TWIN BOOKCASE
~

by Lassen.
Copenhagen


TWIN BOOKCASE




INSTRUCTIONS FOR TWIN BOOKCASE SMALL/LARGE
OPSÆTNINGSVEJLEDNING TIL TWIN BOOKCASE SMALL/LARGE




1



2




3



4



5



6

TOOL LIST: ALLEN KEY

- 1 Package contents.
- 2 Attach the 4 adjustable screws into the holes in the bottom of the shelving frame. These 4 screws can be adjusted to make the unit stable.
- 3 Attach one single cross piece at the bottom and one single cross piece at the top on the opposite side, to stabilise the construction. Be aware that the laquered steel is scratch sensitive.
- 4 Fasten the cross pieces in place with the appropriate screws, making sure that they are well tightened.
- 5 The remaining cross pieces can now be attached.
- 6 Finally, rest the shelves on the frame.

VÆRKTØJSLISTE: UMBRAKONØGLE

- 1 Pakkens indhold.
- 2 Monter de 4 stilleskruer i hullerne i bunden af gavlen. Disse 4 skruer kan justeres iff. gulvet.
- 3 Monter én langsgående sprosse øverst og én langsgående sprosse nederst, for bedre stabilitet ved montage af de resterende langsgående srosser. Vær opmærksom på, at de lakerede emner kan være ridsefølsomme.
- 4 De langsgående srosser fæstnes med skruer, sørg for at skruerne er godt efterspændt.
- 5 De resterende srosser monteres.
- 6 Hyldeplacering i rammerne.

It is suggested that maximum load of the shelves does not exceed more than 60 kg.
Max vægt på hylderne bør ikke overstige 60 kg.